



1. Line up leg inside of the welt cord.
2. Attach the two 5/16" bolts with a 1/2" socket.
3. Drive in the 5 screws.